



2007 GS




■ Adjust clock

With navigation system: → "Navigation System Owner's Manual".
Without navigation system: Perform the following steps.

STEP 1 Press .

STEP 2 Touch .



- 1** Adjust hours.
 - 2** Adjust minutes.
 - 3** Round the nearest hour.
 - 4** Turn daylight saving time on.
 - 5** Turn daylight saving time off.
- After setting, touch .

-
- The clock is displayed when
The engine switch is in "ACC" or "IG-ON" mode.
 - When the battery is disconnected
The time display will automatically be set to 1:00.