

# 2004 LS 430 w/ Navigation

The clock in this system can be corrected manually or by using signals from the GPS. Daylight Saving Time setting or your desired time setting is available.

1. Push the "OPTION" switch.



2. Touch "Adjust Clock".



**Auto Adjust ON:** When you touch this switch, the time is set to the GPS clock, and this switch is highlighted in green.

**Auto Adjust OFF:** To reset the hour, touch the "H" switch. To reset the minute, touch the "M" switch. To adjust the time to the nearest hour, touch ":00" switch.

**Daylight Saving Time:** Daylight saving time can be set or canceled.

While daylight saving time is set, this switch is highlighted in green.

**Time Zone:** You can select the time zone. Touching this switch changes to the time zone selection screen.

Touch the switch of your desired area. The time zone for the area is set and the previous screen returns.