


2006 LS 430



The diagram shows the clock control panel with three buttons labeled H (1), M (2), and :00 (3). A callout box above the panel shows the time 10:00 and two ranges: 9:30 - 9:59 with a red arrow pointing right to 10:00, and 10:01 - 10:29 with a red arrow pointing left to 10:00. The digital display shows 10:00.

- 1** H button : Adjusts the hour.
- 2** M button : Adjusts the minutes.
- 3** :00 button : Resets the minutes to zero.*

*For example:
9:30 to 9:59 displayed → 10:00
10:01 to 10:29 displayed → 10:00

■ Operational condition

The ignition switch must be turned to ON or ACC for the clock to illuminate.